



## BED SIDE HOLE CAP INSTALLATION

The MAR-K bed side “hole cap” fits into the curl of the bed side to dress up the end of the bed. It has an O-ring that will aid in making a good fit. Due to the many model years of usage and the variations from one truck to the next, the parts may not fit perfectly, especially if your bed side has had minor damage. You may have to file the aluminum slightly or reshape the curl opening if there is a tight spot. Once the parts fit in the bed side and when you are ready to permanently install them, apply some epoxy or other durable adhesive to the O-ring area before inserting them into the bed side curl. This will help prevent them from falling out or being easily stolen.



Special instructions for installing on a 67-87 GM stepside. The O-ring must be cut to allow it to fit into the curl opening. The adhesive will keep the O-ring in the curl cap groove during installation and prevent the cap from falling out of the bed side curl. If the curl caps are “Bowtie” machined, the passenger and driver side parts are different and should not be interchanged.