

**TAILGATE LINK ASSEMBLIES FOR ORIGINAL GM, FORD AND DODGE IN STAINLESS OR STEEL**



**MAR-K™** makes tailgate link assemblies for custom applications for removal of chains on original tailgates. Available in brightly polished stainless steel or zinc-plated steel for corrosion resistance. These kits require

modification to the bed sides and tailgate. Each pair includes links, upper and lower pivot points, hardware, installation template and instructions. Available for GM, Ford and Dodge trucks. Stainless links shown. **Made by MAR-K™ in Oklahoma City, USA.**

**GM Stepside/Fleetside**

102982S	34-40 STEPSIDE STAINLESS .....	\$160.00	pr
102982	34-40 STEPSIDE STEEL .....	84.00	pr
102835S	41-53 STEPSIDE STAINLESS .....	160.00	pr
102835	41-53 STEPSIDE STEEL .....	84.00	pr
102834S	54-87 STEPSIDE STAINLESS .....	160.00	pr
102834	54-87 STEPSIDE STEEL .....	84.00	pr
102837S	58-66 FLEETSIDE STAINLESS .....	172.00	pr
102837	58-66 FLEETSIDE STEEL .....	99.00	pr
103023S	67-72 FLEETSIDE STAINLESS .....	184.00	pr

**FORD Flareside (Stepside)**

102882S	53-72 SHORT FLARE STAINLESS .....	\$160.00	pr
102882	53-72 SHORT FLARE STEEL .....	84.00	pr
102883S	76-87 SHORT/53-79 LONG STAINLESS ...	160.00	pr
102883	76-87 SHORT/53-79 LONG STEEL .....	84.00	pr

**DODGE Stepside**

130212S	48-85 HIGHSIDE STEP STAINLESS .....	\$160.00	pr
130212	48-85 HIGHSIDE STEP STEEL .....	84.00	pr

**TAILGATE LATCHES FOR ORIGINAL GM, FORD AND DODGE TAILGATES**



**MAR-K™** makes tailgate latches with a unique "locking" system that allows them to stay in the open position. These are spring-loaded and used in custom applications for replacing the old tail-

gate chains. Zinc plated or stainless steel (for GM and Dodge). Each pair includes latches, installation hardware and complete instructions. Stainless latches shown. **Made by MAR-K™ in Oklahoma City, USA.**

**GM Stepside/Fleetside**

100265S	34-39/41-87 STEPSIDE STAINLESS .....	\$111.00	pr
100265	34-39/41-87 STEPSIDE STEEL .....	93.00	pr
100266S	58-66 FLEETSIDE STAINLESS .....	123.00	pr
100266	58-66 FLEETSIDE STEEL .....	105.00	pr

**FORD Flareside (Stepside)**

102884	53-87 FLARESIDE STEEL .....	\$93.00	pr
--------	-----------------------------	---------	----

**DODGE Highside Stepside**

130213S	48-85 HIGHSIDE STEPSIDE STAINLESS ..	\$130.00	pr
130213	48-85 HIGHSIDE STEPSIDE STEEL .....	\$118.00	pr

**TAILGATES LATCHES & LINKS**



**A MAR-K™ employee attaches two link pieces to each other using this special pressing tool.**

**FORD ROTARY STYLE TAILGATE LATCHES AND STAINLESS OR STEEL LINK ASSEMBLIES**



**MAR-K™** now makes a kit for installing the hidden rotary style latches and link assemblies into a stock Ford tailgate. Adapter panel is made of 16 gage electro-galvanized steel and link assemblies are available

in brightly polished stainless steel or zinc-plated steel. Includes customizing kit for your tailgate and complete instructions. Requires modification to the tailgate and bed sides. **Made by MAR-K™ in Oklahoma City, USA.**

**FORD Flareside (Stepside)**

120284S	53-72 SHORT FLARESIDE STAINLESS ..	\$258.00	pr
120284	53-72 SHORT FLARESIDE STEEL .....	179.00	pr
120285S	76-87 SHORT/53-79 LONG STAINLESS ..	258.00	pr
120285	76-87 SHORT/53-79 LONG STEEL .....	179.00	pr

**TOOLS TO HELP INSTALL**

**17/32" DRILL BIT:** It is used in the installation of **MAR-K™** Tailgate Link Assemblies for Dodge 48-85 Highside Stepside and Ford 53-87 Flareside trucks and GM 34-39 tailgates with hidden latch and link.

**5/8" HOLE SAW:** This is used in the installation of **MAR-K™** hidden latches on GM Stepside, GM 58-66 Fleetside and Ford Flareside trucks. The tool is complete with hole saw, arbor, and 1/4" pilot drill.

**BED SIDE MODIFICATION KIT:** Kit used to install **MAR-K™** link assembly on some GM 60-66 Fleetside trucks. The original bracket attached to the bed sides that the pivot bolt threads into must be removed. On most trucks this bracket is bolted in place from the factory. Some trucks however, the original bracket may have been welded in place. If this is the case, then you need the bed side modification kit.

**Tools to Help Install**

50622	17/32" DRILL BIT .....	\$34.00	ea
50623	5/8" HOLE SAW .....	34.00	ea
100291	BEDSIDE MODIFICATION KIT .....	28.00	kit