

**61-72 FORD FLARESIDE  
BED MOUNTING BLOCK**

**INSTALLATION GUIDELINES**

- A) CONTENTS: Short flareside: 4 small blocks with holes centered.
- B) These wooden blocks are made to support the center two cross sills on the frame.
- C) The wooden blocks fit up into the u-shaped cross sill from the bottom and line up side-to-side with the bed-to-frame bolt location of the cross sill. See diagram on back side.
- D) At each of the bed-to-frame bolt locations, you may wish to use rubber pads between the blocks and the frame. These are available through Mar-K but are not original equipment.

© Copyright 1997, all rights reserved

---

**61-72 FORD FLARESIDE  
BED MOUNTING BLOCK**

**INSTALLATION GUIDELINES**

- A) CONTENTS: Short flareside: 4 small blocks with holes centered.
- B) These wooden blocks are made to support the center two cross sills on the frame.
- C) The wooden blocks fit up into the u-shaped cross sill from the bottom and line up side-to-side with the bed-to-frame bolt location of the cross sill. See diagram on back side.
- D) At each of the bed-to-frame bolt locations, you may wish to use rubber pads between the blocks and the frame. These are available through Mar-K but are not original equipment.

© Copyright 1997, all rights reserved

---

**61-72 FORD FLARESIDE  
BED MOUNTING BLOCK**

**INSTALLATION GUIDELINES**

- A) CONTENTS: Short flareside: 4 small blocks with holes centered.
- B) These wooden blocks are made to support the center two cross sills on the frame.
- C) The wooden blocks fit up into the u-shaped cross sill from the bottom and line up side-to-side with the bed-to-frame bolt location of the cross sill. See diagram on back side.
- D) At each of the bed-to-frame bolt locations, you may wish to use rubber pads between the blocks and the frame. These are available through Mar-K but are not original equipment.

© Copyright 1997, all rights reserved

---

